

2. Engineering and Configuration Tools

Basic license:	<p>Limited access for ADW Config software. Available with or without networking* visualization. Only read functions and the following write functions are possible:</p> <ul style="list-style-type: none"> • Change the current program (e.g. X01-X03, A11,B11 etc.) No change of parameters in the X01-X03 programs. • Project texts • FW-download • RTC clock adjustment • Change the tool language
Programming license:	<p>Full access to all available ADW Config software functions. Only available after Securiton training.</p>
Networking license:	<p>Networking Up to 250 ADW 535 can be networked between each other, in order to configure and visualize devices from one central location. The networking takes place via RS 485 with SIM 35 and SMM 535 or Ethernet. A combination of both transmission media is possible. The networking can be added to the Basis license and Programming licenses</p>

Dongle order form available on the Securiton Homepage:

<http://www.securiton.com>

ADW HeatCalc

Description	Type	Art. Nr.
ADW calculation& planning tool, Configuration and test software. Download from the Storebox / Partnerdata.	ADW-HeatCalc	11-1300005-01-01

Dongle for Securiton Applications (without license)

Description	Type	Art. Nr.
Dongle for Securiton Applications (without license)	ULM-DP	VE100450
Dongle for Securiton Applications (without license) Pack of 5	ULM-DP 5	VE100451
Dongle for Securiton Applications (without license) Pack of 10	ULM-DP 10	VE100452

ADW Dongle (User Level, Limited access rights)

Description	Type	Art. Nr.
ADW Config Basic License	LIC ADW	VE100418
ADW Config Programming full access (only in combination with Basic License ADW available)	LIC ADW Prog	VE100419
ADW Config Networking to configure and visualize	LIC ADW Net	VE100420